

CONVERTITORE DEP TERMOCORDIE Z-8TC CON ISOLAMENTO A SELPLINTI

Descrizione Generale
Lo strumento Z-8TC è un convertitore digitale per termocoppie, con otto canali di misura. isolati dall'alimentazione e dalla linea di comunicazione seriale fino a 1.5 kV. Lo stesso isolamento pari a 1.5 kV è previsto tra canali facenti capo a gruppi diversi di morsetti. Il modulo è dunque caratterizzato da un isolamento complessivo a sei punti. In aggiunta esso è caratterizzato da:

- Cablaggio facilitato dell'alimentazione e del bus seriale per mezzo del bus alloggiato nella guida DIN.
- Configurabilità della comunicazione tramite DIP-switch o via software.
 Comunicazione seriale RS485 con protocollo MODBUS -RTU, massimo 32 nodi.
- Protezione contro scariche ESD fino a 4 kV.
- Elevata velocità di acquisizione
- Misura di termocoppie: J, K, E, N, S, R, B, T.
- · Misura degli ingressi disponibile nei seguenti formati: rappresentazione floating-point, floating-point inversa, virgola fissa a 16 bit, in decimi di grado con segno per la temperatura, decine di uV per la tensione
- Canali attivabili singolarmente.
- Valore programmabile in caso di fault o congelamento ultima lettura .

Per ciascuna coppia di ingressi relativi allo stesso gruppo di morsetti sono previste le seguenti impostazioni comuni:

- Misura impostabile in temperatura o mV.
- Filtro programmabile a otto livelli per la stabilizzazione della lettura.
- Rejezione programmabile a 50 Hz o 60 Hz.
- Tre diverse velocità di acquisizione selezionabili (due a 14 bit, una a 15 bit).
- Compensazione giunto freddo.

	<u>ristiche</u>	Tecniche

Alimentazione : Consumo :	1040 Vdc o 1928 Vac (5060 Hz). max 0,6 W.
Porte di Comunicazione Seriale :	-RS232, 2400 Baud, Indirizzo:01, Parità: NO, Dati:
Protocollo :	bit; Stop bit: 1. MODBUS-RTU.

-10.1..81.4 mV

10 MΩ.

Termocoppia di tipo: J, K, E, N, S, R, B, T.

ADC 14 bit e Reiez. 50 Hz: \pm (0,040 % + 13 μ V). ADC 15 bit e Reiez. 50 Hz: ±(0,035 % + 10 µV). ADC 14 bit e Reiez, 60 Hz; +(0.045 % + 16 µV). ADC 15 bit e Reiez, 60 Hz; ± (0,040 % + 12 µV).

Inaressi

Ingresso

EN60584-1 (ITS-90) Range di temperatura Dipendente dal tipo di termocoppia (vedere Tabella Range Termocoppie)

Span mV: Impedenza

Errore complessivo

SSENECA

MI001230-I

ITALIANO - 1/16

DMRR :::	PANCE TERMOCOPPIE
CMRR (1): DMRR (1)(2):	>155 dB (porta in prova verso tutte le altre a GND). >60 dB.
Corrente Test :	<50 nA.

TOTAL TERMINOUT I IE								
TIPO TC	Range	Errore	TIPO TC	Range	Errore			
111-0-10	Ammesso	Linearizzazione	111 0 10	Ammesso	Linearizzazione			
J	-2101200 °C	0,05 °C	S	-501768 °C	0,02 °C			
K	-2001372 °C	0,05 °C	R	-501768 °C	0,02 °C			
E	-2001000 °C	0,02 °C	В	2501820 °C (3)	0,03 °C			
N	-2001300 °C	0,04 °C	T	-200400 °C	0,04 °C			

N	-2001300 °C	0,04 °C	T	-200400 °C	0,04 °C		
Altre Carat	teristiche						
ADC :			ile a 14 o 1	5 bit.			
Deriva Terr		< 100 pp					
Reiezione a			ile a 50 Hz	o a 60 Hz.			
	to Freddo :	<1 °C.					
Tensione di	isolamento :	ingresso			comunicazione e morsetti diversi.		
Grado di pr		IP20.					
Condizioni		EEPRON Umidità Altitudine	Temperatura -10+65 °C, Salvataggio parametri i EEPROM garantito nel range: 050 °C. Umidità 3090 % non condensante. Altitudine 2000 slm				
Temp. Stoc		-20+85					
Segnalazio Connessior	ii:	Alimentazione, Fail, Comunicazione RS485. -Morsetti a vite estraibili a 4 vie, max 1.5 mm², pass 3.5 mm. -Connettore posteriore IDC10 per barra DIN. -Jack frontale stereofonico 3.5 mm per connession RS232 (COM).					
Contenitore		PBT, cold					
Dimensioni	Peso:		2 x 17,5 mn				
Normative :	Ξ€	ambiente EN61000 ambiente EN61010 Tutti i c isolamer trasforma	e industriale 0-6-2/2006- e industriale 0-1/2001 (si ircuiti devo to dai circu atore di alim). 10 (immunità e). curezza). no essere iso uiti sotto tension entazione deve	elettromagnetica, elettromagnetica, lati con doppio ne pericolosa. Il essere a norma isolamento e		

(1) I valori sono validi alla frequenza di rejezione impostata, con il filtro inserito.

(2) Per valori del disturbo tali che il picco del segnale d'ingresso non ne superi l'accettabilità. (3) Fino a 250 °C si assume un valore di temperatura nulla.

trasformatori di sicurezza"

SENECA

Norme di installazione

Il modulo è progettato per essere montato su quida DIN 46277, in posizione verticale. Per un funzionamento ed una durata ottimale, è necessario assicurare una adeguata ventilazione al/ai moduli, evitando di posizionare canaline o altri oggetti che occludano le feritoje di ventilazione


Evitare il montaggio dei moduli sopra ad apparecchiature che generano calore: è consigliabile il montaggio nella parte bassa del quadro.

Collegamenti Elettrici

PORTA SERIALE RS485 E ALIMENTAZIONE


I collegamenti elettrici relativi al bus RS485 e all'alimentazione sono disponibili esclusivamente utilizzando il bus per guida DIN Seneca.

I collegamenti del connettore del bus per guida DIN sono visibili nella figura seguente



PORTA SERIALE RS232

Il cavo di connessione DB9, lack stereo 3.5 mm nuò essere assemblato come indicato nella figura seguente, oppure acquistato come accessorio. Si evidenzia inoltre che il GND della RS232 è il medesimo della RS485.






MI001230-I

ITALIANO - 3/16

INGRESSI

Il modulo accetta in ingresso termocoppie di tipo: J, K, E, N, S, R, B, T. Per i collegamenti elettrici si raccomanda l'utilizzo di cavo schermato



Le coppie di canali facenti parte dello stesso gruppo di morsetti hanno il terminale di massa internamente connesso e non sono isolati tra loro. È invece garantito un isolamento pari a 1,5 kV tra canali relativi a gruppi di morsetti diversi.

Indicazioni tramite LED sul frontale

SENECA

LED PWR (VERDE)	Significato Indica la presenza dell'alimentazione.			
Acceso				
LED ERR (GIALLO)	Significato			
Acceso	Guasto: alimentazione insufficiente, canale guasto,TC guasta, errore di comunicazione interna (segnalati se il canale corrispondente è attivato).			
LED RX (ROSSO)	Significato			
Acceso	Indica la ricezione di dati sulla porta di comunicazione RS485.			

MI001230-I ITALIANO - 4/16

LED TX (ROSSO)	Significato
Acceso	Indica la trasmissione di dati sulla porta di comunicazione RS485.

Interfaccia Seriale

Per informazioni dettagliate sull'interfaccia seriale RS485 fare riferimento alla documentazione presente nel sito www.seneca.it, nella sezione Prodotti/Serie Z-PC/MODBUS TUTORIAL

IMPOSTAZIONE DEI DIP-SWITCH

Configurazione di Fabbrica

Lo strumento esce dalla fabbrica configurato con tutti i DIP-switch in posizione 0. La posizione dei dip-switch definisce i parametri di comunicazione del modulo: indirizzo e

In tutte le tabelle seguenti l'indicazione o corrisponde a DIP-switch in 1 (ON); nessuna indicazione corrisponde a DIP-switch in 0 (OFF)

VELO	OC	ITÀ										
SW1	1	2										
			9600 Baud									
		•	19200 Baud									
	•	П	38400 Baud									
	● 57600 Baud		57600 Baud									
	_	_										

INDIR	INDIRIZZO								
SW1	3	4	5	6	7	8			
							Parametri di comunicazione da EEPROM (4)		
						•	Indirizzo fisso 01		
					•		Indirizzo fisso 02		
					•	•	Indirizzo fisso 03		
				•		П	Indirizzo fisso 04		
	Х	Х	Χ	Χ	Х	Х	Indirizzo fisso, come da rappresentazione binaria		
	•	•	•	•	•	•	Indirizzo fisso 63		

3441	9	INOTI USALO						
	Lasciare in posizione OFF.							
TER	TERMINAZIONE RS485							
SW1	10							
		Nessuna Terminazione di linea						
	•	Terminatore di linea inserito						

⁽⁴⁾ La configurazione di default è la seguente: Indirizzo 1, 38400, no parity, 1 bit di stop.



MI001230-I

ITALIANO - 5/16

ITALIANO - 6/16

IMPOSTAZIONE DI DEFAULT CANALI INGRESSO

La configurazione di default, valida per ciascuna coppia di canali relativi allo stesso gruppo di morsetti è la sequente

Entrambi i canali abilitati

Dato restituito Compensazione giunto freddo: Attiva Reizione

ADC / Filtro ADC 15 bit con filtro in media Tipo Termocoppia J per entrambi i canali.

IMPOSTAZIONE FILTRO

Per ogni gruppo di canali è possibile impostare le modalità di filtratura. Il filtro è composto da due filtri passa basso indipendenti:

- Filtro FIR, in media mobile in grado di aumentare la reiezione ai disturbi alla frequenza di rete e di ridurre il rumore di misura

- Filtro IIR esponenziale, con costante di tempo programmabile, in grado di smorzare le

Se viene rilevata una variazione dell'ingresso superiore alla soglia S. entrambi i filtri vengono forzati ad adeguarsi rapidamente al nuovo valore, per intervenire solo successivamente a stabilizzarlo. Il valore della soglia è fisso in tensione e pari a circa 0,75 mV. Il filtro viene impostato tramite i tre bit meno significativi dei registri MODBUS 40054..57 (fare riferimento alla sezione REGISTRI MODBUS).

Di seguito si riporta una tabella con tutti i tipi di filtraggio impostabili. Per ciascuno di questi viene inoltre riportato il tempo di propagazione (90%), cioè il tempo massimo che trascorre tra la variazione a gradino dell'ingresso e la variazione del numero che la rappresenta nel registro Modbus, compreso il tempo di interrogazione del singolo registro (a 115 kbaud). I tempi riportati in tabella valgono se sono rispettate entrambe le sequenti condizioni :

- Reiezione a 50 Hz. Se a 60 Hz dividere i tempi riportati per 1,2.
- Abilitazione di una sola delle due termocoppie del gruppo. Se entrambe le termocoppie sono abilitate i tempi con buona approssimazione raddoppiano.

SET	SAMI	LING	FILTRO	TEMPO PROP. 90%		
SEI	Bit ADC	Hz	TIPO	<\$	>S	
000	14	48	Non presente	45 ms	45 ms	
001	14	20	Media	236 ms	103 ms	
010 (5)	15	11	Media	405 ms	179 ms	
011	15	11	Media + exp	1 s	179 ms	
100	15	11	Media + exp	3 s	179 ms	
101	15	11	Media + exp	8 s	179 ms	
110	15	11	Media + exp	24 s	179 ms	
111	15	11	Media + exp	72 s	179 ms	

MI001230-I

SENECA

Programmazione


Per i tool di programmazione e/o configurazione del prodotto consultare il sito www.seneca.it.

Durante la prima programmazione è possibile utilizzare le impostazioni di default da FEPROM (SW1.3.8 in posizione OFF) che sono all'origine programmate come segue: Indirizzo=001. VELOCITA'=38400 Baud. PARITA'=nessuna. NUMERO BIT=8. STOP

La programmazione del modulo può essere effettuata anche attraverso il connettore frontale (COM), facendo attenzione ad impostare i seguenti parametri per il collegamento: Indirizzo=001, Velocità=2400 Baud, PARITA'=nessuna, STOP BIT = 1.

La porta di comunicazione COM si comporta esattamente come quella del bus RS485 eccetto che per i parametri di comunicazione come già descritto. Inoltre ha priorità sulla porta RS485 e viene chiusa dopo 3 s di inattività.

Pannello Frontale e Posizione Led






MI001230-I

ITALIANO - 7/16

Dimensioni e Ingombri



Questo documento è di proprietà SENECA srl. La duplicazione e la riproduzione sono vietate, se non autorizzate. Il contenuto della presente documentazione corrisponde ai prodotti e alle tecnologie descritte. I dati riportati potranno essere modificati o integrati per esigenze tecniche e/o commerciali. Il contenuto della presente



SENECA s.r.l.

Via Germania, 34 - 35127 - Z.I. CAMIN - PADOVA - ITALY Tel. +39.049.8705355 - 8705359 - Fax +39.049.8706287 e-mail: info@seneca.it - www.seneca.it



⁽⁵⁾ Valore di default

REGISTRI MODBUS

Il modulo Z-8TC dispone di registri MODBUS a 16 bits (words) accessibili tramite comunicazione seriale RS485 o RS232. Nei prossimi paragrafi si descrivono i comandi MODBUS supportati e le funzionalità esprimibili dai vari registri.


Comandi MODBUS supportati

Codice	Funzione	Descrizione
03 (*)	Read Holding Registers	Lettura di registri a word fino a 32 per volta
04 (*)	Read Input Registers	Lettura di registri a word fino a 32 per volta
06	Write Single Register	Scrittura di un registro a word
16	Write Multiple Registers	Scrittura di registri a word fino a 32 per volta

(*) Le due funzioni hanno lo stesso effetto

Holding Registers

I registri Holding Registers a 16 bits hanno la seguente struttura :



La notazione Bit [x:y] riportata in tabella indica tutti i bit dal x a y. Ad esempio Bit [2:1] indica il bit 2 e il bit 1, e serve ad illustrare il significato delle varie combinazioni congiunte di valori dei due bit. Da ricordare che sui seguenti registri possono essere eseguite le funzioni MODBUS 3, 4, 6 e 16, di lettura e scrittura singola e multipla. I valori contrassegnati con il simbolo * sono quelli di default.

REGISTRO	Descrizione	IND.	R/W
MACHINE ID	40001	R	
STATUS_INP	Stato dei canali d'ingresso	40002	R
Bit 15	1: Guasto ai canali 1 e 2.		
Bit 14	1: Guasto ai canali 3 e 4.		
Bit 13	1: Guasto ai canali 5 e 6.		
Bit 12	1: Guasto ai canali 7 e 8.		
Bit 11	1: Guasto alla TC collegata al canale 1.		



SSENECA

MI001230-I

ITALIANO - 9/16

Bit 10	1: Guasto alla TC collegata al canale 2.									
Bit 9	1: Guasto alla TC collegata al canale 3.									
Bit 8	1: Guasto alla TC collegata al canale 4.									
Bit 7	1: Guasto alla TC collegata al canale 5.									
Bit 6	1: Guasto alla TC collegata al canale 6.									
Bit 5	1: Guasto alla TC collegata al canale 7.									
Bit 4	1: Guasto alla TC collegata al canale 8.									
Bit 3	1: Errore Comunicazione con i canali 1 e 2.									
Bit 2	1: Errore Comunicazione con i canali 3 e 4.									
Bit 1	1: Errore Comunicazione con i canali 5 e 6.									
Bit 0	1: Errore Comunicazione con i canali 7 e 8.									
CHAN1 DEC	Misura canale 1 (in decimi di °C o decine 40003 R									
_	diμV)									
Bit [15:0]	Temperatura in decimi di °C del canale 1 (o									
	tensione in decine di µV).									
CHAN2_DEC	Misura canale 2 (in decimi di °C o decine 40004 R									
	<u>diμV)</u>									
Bit [15:0]	Temperatura in decimi di °C del canale 2 (o									
	tensione in decine di µV).									
CHAN3_DEC	Misura canale 3 (in decimi di °C o decine 40005 R									
	diμV)									
Bit [15:0]	Temperatura in decimi di °C del canale 3 (o tensione in decine di μV).									
CHAN4 DEC	Misura canale 4 (in decimi di °C o decine 40006 R									
OHANT_DEG	di μV)									
Bit [15:0]	Temperatura in decimi di °C del canale 4 (o									
Dit [10.0]	tensione in decine di μV).									
CHAN5_DEC	Misura canale 5 (in decimi di °C o decine 40007 R									
	<u>di μV)</u>									
Bit [15:0]	Temperatura in decimi di °C del canale 5 (o									
	tensione in decine di μV).									
CHAN6_DEC	Misura canale 6 (in decimi di °C o decine 40008 R									
	diμV)									
Bit [15:0]	Temperatura in decimi di °C del canale 6 (o tensione in decine di μV).									
CHAN7 DEC	Misura canale 7 (in decimi di °C o decine 40009 R									
CHAN/_DEC	di uV)									
Bit [15:0]	Temperatura in decimi di °C del canale 7 (o									
Dit [13.0]	tensione in decine di µV).									

MI001230-I

CHAN8_DEC	Misura canale 8 (in decimi di °C o decine di μV)	40010	R				
Bit [15:0]	Temperatura in decimi di $^{\circ}$ C del canale 8 (o tensione in decine di μ V).						
CHAN1_FLOAT_H	Misura canale 1 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	15 40011 R					
Bit [15:0]	Temperatura in °C o tensione in mV del canale 1 (MSW del float).						
CHAN1_FLOAT_L	Misura canale 1 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	40012	R				
Bit [15:0]	Temperatura in °C o tensione in mV del canale 1 (LSW del float).	·					
CHAN2_FLOAT_H	Misura canale 2 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	40013	R				
Bit [15:0]	Temperatura in °C o tensione in mV del canale 2 (MSW del float).						
CHAN2_FLOAT_L	Misura canale 2 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	40014	R				
Bit [15:0]	Temperatura in °C o tensione in mV del canale 2 (LSW del float).						
CHAN3_FLOAT_H	Misura canale 3 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	40015	R				
Bit [15:0]	Temperatura in °C o tensione in mV del canale 3 (MSW del float).	,					
CHAN3_FLOAT_L	Misura canale 3 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	5 40016 R					
Bit [15:0]	Temperatura in °C o tensione in mV del canale 3 (LSW del float).						
CHAN4_FLOAT_H	Misura canale 4 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	40017	R				
Bit [15:0]	Temperatura in °C o tensione in mV del canale 4 (MSW del float).						
CHAN4_FLOAT_L	Misura canale 4 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	40018	R				
Bit [15:0]	Temperatura in °C o tensione in mV del canale 4 (LSW del float).						
CHAN5_FLOAT_H	Misura canale 5 in floating point (vedi bit 15 registro 40058 "AUX_SETTINGS")	40019	R				
Bit [15:0]	Temperatura in °C o tensione in mV del canale 5 (MSW del float).						

SENECA

MI001230-I ITALIANO - 11/16

<i></i>			,
HAN5_FLOAT_L	Misura canale 5 in floating point (vedi bit 15 AUX_SETTINGS 40058)		R
tit [15:0]	Temperatura in °C o tensione in mV del canale 5 (LSW del float).		
HAN6_FLOAT_H	Misura canale 6 in floating point (vedi bit 15 AUX_SETTINGS 40058)	40021	R
it [15:0]	Temperatura in °C o tensione in mV del canale 6 (MSW del float).		
HAN6_FLOAT_L	Misura canale 6 in floating point (vedi bit 15 AUX_SETTINGS 40058)	40022	R
Bit [15:0]	Temperatura in °C o tensione in mV del canale 6 (LSW del float).		
HAN7_FLOAT_H	Misura canale 7 in floating point (vedi bit 15 AUX_SETTINGS 40058)	40023	R
Bit [15:0]	Temperatura in °C o tensione in mV del canale 7 (MSW del float).		
HAN7_FLOAT_L	Misura canale 7 in floating point (vedi bit 15 AUX_SETTINGS 40058)	40024	R
Sit [15:0]	Temperatura in °C o tensione in mV del canale 7 (LSW del float).		
HAN8_FLOAT_H	Misura canale 8 in floating point (word più significativa)	40025	R
Sit [15:0]	Temperatura in °C o tensione in mV del canale 8 (MSW del float).		
HAN8_FLOAT_L	Misura canale 8 in floating point (vedi bit 15 AUX_SETTINGS 40058)	40026	R
it [15:0]	Temperatura in °C o tensione in mV del canale 8 (LSW del float).		
TATUS_INP	Copia del registro 40002 contenente lo stato dei canali di ingresso	40027	R
IUNTO_DEC_IN1_2	Misura temperatura giunto freddo canali 1 e 2	40028	R
Bit [15:0]	Temperatura in decimi di °C del giunto freddo relativo ai canali 1 e 2.		
IUNTO_DEC_IN3_4	Misura temperatura giunto freddo canali 3 e 4	40029	R
Sit [15:0]	Temperatura in decimi di °C del giunto freddo relativo ai canali 3 e 4.		
SIUNTO_DEC_IN5_6	Misura temperatura giunto freddo canali 5 e 6	40030	R
Bit [15:0]	Temperatura in decimi di °C del giunto freddo relativo ai canali 5 e 6.		

GIUNTO_DEC_IN7_8	UNTO_DEC_IN7_8 Misura temperatura giunto freddo canali 7e 8 4003						
Bit [15:0]	Temperatura in decimi di °C del giunto freddo relativo ai canali 7 e 8.	ldo					
ERR_CH1-2_CH3-4	Errori Canali 1, 2 (MSB), Canali 3, 4 (LSB)	40037 R					
Bit 15	1: Errore tensione alimentazione (canale 1 e 2).						
Bit 14	1: Errore di ricezione (canali 1 e 2).						
Bit 13	1: Errore salvataggio EEPROM (canali 1 e 2).						
Bit 12	1: Salvataggio EEPROM bloccato (canali 1 e 2).						
Bit [11:9]	Riservati.						
Bit 8	1: Errore lettura CRC EEPROM (canali 1 e 2).						
Bit 7	1: Errore tensione alimentazione (canali 3 e 4).						
Bit 6	1: Errore di ricezione (canali 3 e 4).						
Bit 5	1: Errore salvataggio EEPROM (canali 3 e 4).						
Bit 4	1: Salvataggio EEPROM bloccato (canali 3 e 4).						
Bit [3:1]	Riservati.						
Bit 0	1: Errore lettura CRC EEPROM (canali 3 e 4).						
ERR_CH5-6_CH7-8	40038	R					
Bit 15	1: Errore tensione alimentazione (canale 5 e 6).						
Bit 14	1: Errore di ricezione (canali 5 e 6).						
Bit 13	1: Errore salvataggio EEPROM (canali 5 e 6).						
Bit 12	1: Salvataggio EEPROM bloccato (canali 5 e 6).						
Bit [11:9]	Riservati.						
Bit 8	1: Errore lettura CRC EEPROM (canali 5 e 6).						
Bit 7	1: Errore tensione alimentazione (canali 7 e 8).						
Bit 6	1: Errore di ricezione (canali 7 e 8).						
Bit 5	1: Errore salvataggio EEPROM (canali 7 e 8).						
Bit 4	1: Salvataggio EEPROM bloccato (canali 7 e 8).						
Bit [3:1]	Riservati.						
Bit 0	1: Errore lettura CRC EEPROM (canali 7 e 8).						
RESET	Reset del modulo	40041	R/V				
Bit [15:0]	Scrivendo il valore 0xCCCC, viene comandato il reset (riavvio) del modulo.						

SENECA

SSENECA

MI001230-I ITALIANO - 13/16

ADDR (6) (7)	Registro per l'impostazione dell'indirizzo del modulo e del controllo di parità	40052	R/W
Bit [15:8]	Impostano l'indirizzo del modulo. Valori ammissibili da 0x00 a 0xFF (valori decimali nell'intervallo 0-255, Default: 1).		
Bit [7:0]	Impostano il tipo di controllo sulla parità: 00000001 : nessuna parità (NONE) 0000001 : parità pari (EVEN) 00000010 : parità dispari (ODD)		
BAUDR (6) (7)	Registro per l'impostazione del baudrate e del tempo di ritardo della risposta	40053	R/W
Bit [15:8]	Impostano il valore della velocità di comunicazione seriale (baudrate) : 00000000 (0x00): 4800 Baud 0000001 (0x01): 9600 Baud 0000001 (0x02): 19200 Baud 00000011 (0x02): 19200 Baud 00000110 (0x04): 57600 Baud 00000110 (0x06): 116200 Baud 00000110 (0x06): 1200 Baud 00000111 (0x06): 1200 Baud 00000111 (0x07): 2400 Baud 10x07): 2400 Baud 10x07011 (0x07): 2400 Baud 10x070		
ык (7:0)	Rappresenta il numero di pause da 6 caratteri ciascuna da inserire tra la fine del messaggio Rx e l'inizio del messaggio Tx. Il valore di default è 0x00 (valore decimale 0).		
CONF_CH1_CH2 (6)	Configurazione Canali 1 e 2	40054	R/W
Bit 15	Attivazione Canale 1: 0 : Canale 1 non attivo 1 * : Canale 1 attivo		
Bit 14	Attivazione Canale 2: 0 : Canale 2 non attivo 1 * : Canale 2 attivo		
Bit 13	Tipo dato restituito Canale 1 e Canale 2: 0*: misura in °C 1: misura in mV		
Bit 12	Compensazione Giunto Freddo Canale 1 e Canale 2: 0 : non attiva 1 *: attiva		
Bit 11	Frequenza Reiezione Canale 1 e Canale 2: 0*:50 Hz 1:60 Hz		

Bit [10:8]	Filtro Canali 1 e 2 (per dettagli fare riferimento alla sezione IMPOSTAZIONE FILTRO): 000: Non inserito 001: Filtro in media Altre impostazioni in IMPOSTAZIONE FILTRO.		
Bit [7:4]	Tipo Termocoppia Canale 1 (vedere Tabella TIPO TERMOCOPPIA). Default: Tipo J.		
Bit [3:0]	Tipo Termocoppia Canale 2 (vedere Tabella TIPO TERMOCOPPIA). Default: Tipo J.		
CONF_CH3_CH4 (6)	Configurazione Canali 3 e 4	40055	R/W
Bit [15:0]	Registro per la configurazione dei canali 3 e 4. Vedere il registro 40054, tenendo conto che in questo caso non si fa riferimento ai canali 1 e 2 ma rispettivamente ai canali 3 e 4.		
CONF_CH5_CH6 (6)	Configurazione Canali 5 e 6	40056	R/W
Bit [15:0]	Registro per la configurazione dei canali 5 e 6. Vedere il registro 40054, tenendo conto che in questo caso non si fa riferimento ai canali 1 e 2 ma rispettivamente ai canali 5 e 6.		
CONF_CH7_CH8 (6)	Configurazione Canali 7 e 8	40057	R/W
Bit [15:0]			
AUX_SETTINGS (6)	Registro ausiliario configurazione	40058	R/W
Bit 15	Interpretazione floating point 0 *: Viene trasmessa prima la word alta del floating point, poi quella bassa. 1 : Viene trasmessa prima la word bassa del floating point, poi quella alta.		
Bit [14:8]	Riservati non modificare.		
Bit 7	Azione in caso di fault canale 1: 0 *: Il valore di temperatura/tensione è forzato al valore di fault programmato. 1 : Il valore di temperatura/tensione è congelato all'ultimo valore acquisito prima della segnalazione di fault.		
Bit 6	Azione in caso di fault canale 2 (Come Bit 7).		
Bit 5	Azione in caso di fault canale 3 (Come Bit 7).		
Bit 4	Azione in caso di fault canale 4 (Come Bit 7).		
Bit 3	Azione in caso di fault canale 5 (Come Bit 7).		
Bit 2	Azione in caso di fault canale 6 (Come Bit 7).		
Bit 1	Azione in caso di fault canale 7 (Come Bit 7).		
Bit 1	Azione in caso di fault canale 7 (Come Bit 7).		

SENECA

MI001230-I

ITALIANO - 15/16

Bit 0	Azione in caso di fault canale 8 (Come Bit 7).		
VAL_FAULT_1 (6)	Valore caricato in caso di fault canale 1 (espresso come 40003). (8) Default: 2000,0.	40059	R/W
VAL_FAULT_2 (6)	Valore caricato in caso di fault canale 2 (espresso come 40004). (8) Default: 2000,0.	40060	R/W
VAL_FAULT_3 (6)	Valore caricato in caso di fault canale 3 (espresso come 40005). (8) Default: 2000,0.	40061	R/W
VAL_FAULT_4 (6)	Valore caricato in caso di fault canale 4 (espresso come 40006). (8) Default: 2000,0.	40062	R/W
VAL_FAULT_5 (6)	Valore caricato in caso di fault canale 5 (espresso come 40007). (8) Default: 2000,0.	40063	R/W
VAL_FAULT_6 (6)	Valore caricato in caso di fault canale 6 (espresso come 40008). (8) Default: 2000,0.	40064	R/W
VAL_FAULT_7 (6)	Valore caricato in caso di fault canale 7 (espresso come 40009). (8) Default: 2000,0.	40065	R/W
VAL_FAULT_8 (6)	Valore caricato in caso di fault canale 8 (espresso come 40010). (8) Default: 2000,0.	40066	R/W

TABELLA TIPO TERMOCOPPIA PER IMPOSTAZIONE REGISTRI 40054..40057

BIT		BIT TIPO TERMOCOPPIA			BIT			TIPO TERMOCOPPIA	
7	6	5	4	TC per Canali 1, 3, 5 o 7	3	2	1	0	TC per Canali 2, 4, 6 o 8
0	0	0	0	TC J	0	0	0	0	TC J
0	0	0	1	TC K	0	0	0	1	TC K
0	0	1	0	TC R	0	0	1	0	TC R
0	0	1	1	TC S	0	0	1	1	TC S
0	1	0	0	TC T	0	1	0	0	TC T
0	1	0	1	TC B	0	1	0	1	TC B
0	1	1	0	TC E	0	1	1	0	TC E
0	1	1	1	TC N	0	1	1	1	TC N
1	Y	Y	Y	Non implementate	1	¥	Y	х	Non implementate

(6) Il valore è conservato in EEPROM.

⁽⁸⁾ Il valore nei registri 40059..40066 viene ricopiato rispettivamente nei registri 40003..40010, quando il bit corrispondente del registro 40058 sia a 0. Lo stesso valore viene convertito in floating-point e ricopiato nel registro float relativo al canale.



/ Facciota dimerenziata).
Il simbioto presente sul prodotto o sulla sua confezione indica che il prodotto non verrà trattato come rifluto domestico. Sarà invece consegnato al centro di raccolta autorizzato per il ricicho del fintili elettrici del delitorici. Assicurando viche i prodotto verga smattito in modo adeguato, verderete un potenziale impatto negativo sul amilente le la salutie unana, che potrebbe essere causato da una gestione non conforme dello smalltimento del prodotto. Il riciclaggio dei materiali contribuirà alla conservazione delle risorse naturali. Per ricevere ulteriori informazioni più dettagliate Vi invitiamo a contattare l'ufficio



il servizio per lo smaltimento dei rifiuti o il fornitore da cui avete acquistato il prodotto.

SENECA s.r.I. Via Germania, 34 - 35127 - Z.I. CAMIN - PADOVA - ITALY Tel. +39.049.8705355 - 8705359 - Fax +39.049.8706287



e-mail: info@seneca.it - www.seneca.it

⁽⁷⁾L'effetto si ha al riavvio (hardware o software) dello strumento.

Z-8TC

CONVERTER FOR THERMOCOURLES WITH 6-POINT INSULATION

General Description

The Z-8TC instrument is a digital converter for thermocouples, with eight measuring channels, which are insulated from the power supply and from the serial communication line up to 1.5 kV. The same 1.5 kV insulation is present among the input channels belonging to different groups of terminals. The instrument is therefore characterized by a six points global insulation. Furthermore, the module has:
• Facilitated wiring of power supply and serial bus by means of the bus housed in the DIN

- Communication can be configured by DIP-switch or software.
 RS485 serial communication with MODBUS-RTU protocol. 32 nodes maximum.
- Inputs protected against ESD discharges up to 4 kV.
- High acquisition speed.
- Measurement of thermocouples: J, K, E, N, S, R, B, T.
- · Measurement of the inputs available in the following formats: floating-point representation, reverse floating-point, fixed dot at 16 bits, in tenths degrees with sign for temperature, tenths of uV for voltage
- Channels independently activable
- Programmable value in case of fault or freezing of last reading.

For each pair of inputs belonging to the same group of terminals the following common settings are possible:

- Measurement in temperature or mV
- Filter programmable at eight levels to stabilise reading.
- Rejection programmable at 50 Hz or 60 Hz.
- Three selectable acquisition speeds (two at 14 bits, one at 15 bits).
- Cold Junction Compensation.

recrinical Specifications	
Power Supply:	1040 Vdc or 1928 Vac (5060 Hz).
Consumption :	max 0,6 W.
Serial Communication Ports :	-RS485, 1200115200 Baud. -RS232, 2400 Baud, Address: 1, Parity: NO, Dat bits: 8; Stop bits: 1.
Protocol :	MODBUS-RTU.

Protocol Inputs

Thermocouple types: J, K, E, N, S, R, B, T. Inputs EN60584-1 (ITS-90). Temperature Range Dependent on the thermocouple type (see

Thermocouples Range table). -10,1..81,4 mV. Span mV:

10 MO Impedance Total Error:

14 bits ADC and 50 Hz Rejection: \pm (0,040 % + 13 μ V). 15 bits ADC and 50 Hz Rejection: ±(0.035 % + 10 μV). 14 bits ADC and 60 Hz Rejection : +(0.045 % + 16 µV) 15 bits ADC and 60 Hz Rejection: \pm (0,040 % + 12 μ V).

SSENECA

MI001230-E

ENGLISH -1/16

	THERMOCOUPLES RANGE
OMRR (1) (2):	GND).
CMRR (1):	>155 dB (tested port towards all the other ones at
Test Current :	<50 nA.

THE RING COOK ELD RANGE									
TC TYPE	Allowed	Linearization	TC TYPE	Allowed	Linearization				
ICTIFE	Range	nge Error		Range	Error				
J	-2101200 °C	0,05 °C	S	-501768 °C	0,02 °C				
K	-2001372 °C	0,05 °C	R	-501768 °C	0,02 °C				
E	-2001000 °C	0,02 °C	В	2501820 °C (3)	0,03 °C				
N	-2001300 °C	0,04 °C	T	-200400 °C	0,04 °C				

	-2001000 0	0,02 C		2301620 C	0,05 C
N	-2001300 °C	0,04 °C	Т	-200400 °C	0,04 °C
Other Fea	tures				
ADC :		Settable	to 14 or 15	bits.	
Thermal D	Orift :	< 100 pp			
	ce Rejection :		to 50 Hz or	60 Hz.	
	ction Error :	<1 °C.			
Insulation	Voltage :			g input, powe	er supply and
			ication port		
				channels belon	ging to differen
	_		fterminals.		
	Degree :	IP20.			
Environme	ental conditions :			65 °C, Saving	
				ed in range: 050	°C.
				not-condensing.	
C4 4-			up to 2000 r	ma.s.l.	
	emperature :	-20+85		004050	
Signalling Connection				RS485 Commun	
Connectio	ms:			screw terminals	s,, max 1.5 mm
		3.5 mm p		ctor for DIN rail.	
				nic front jack fo	- Dessa (COM
		-3.5 mm		nic front jack ic	I K5232 (CUN
Box :		PBT, blad			
	ns and weight :		2 x 17,5 mr	n 140 a	
Standards	S'	FN6100	0-6-4/2003	2 (electromagn	netic emission
Otal laal ac			l environme		
				5 (electromagn	netic immunity.
			l environme		
		EN61010	0-1/2001 (s	afetv).	
	$C \in \mathcal{C}$			insulated from t	the other circuits
- (under da	ngerous vo	oltage with doubl	e insulation. The
•				ansformer mus	

transformers". (1) The values are valid at the set rejection frequency, with the filter ON. (2) For disturbance values such as the input signal peak does not exceed the limit of acceptability

EN60742: "Insulated transformers and safety

⁽³⁾ Up to 250 °C: the input is considered equivalent to a null temperature.

SENECA MI001230-E

Installation rules

The module is designed to be installed in vertical position on a DIN 46277 rail. In order to ensure optimum performance and the longest working life, the module(s) must be supplied adequate ventilation and no raceways or other objects that obstruct the


Never install modules above sources of heat: we recommend installation in the lower part of the control panel.

Flectric Connections

POWER SUPPLY AND RS485 COMMUNICATION PORT

The electric connections for power supply and RS485 bus can be made only by using the bus for the Seneca DIN rail.


The connections of the bus connector are described on the following figure.



RS232 SERIAL PORT

Connection cable DB9 with a 3.5 mm stereo Jack, can be assembled as indicated in the following figure, or can be bought as an accessory.

We advise you that the GND of the RS232 is the same of RS485.






MI001230-E

ENGLISH -3/16

INPUTS

The module accepts, at input, the following types of thermocouples: J, K, E, N, S, R, B, T. For the electrical connections, we advise you to use screened cables



The pairs of channels belonging to the same group of terminals, have the GND terminal internally connected and are not insulated each other.

Instead a 1.5 kV insulation is present among the input channels belonging to different

Indications by LED on the frontal panel

PWR LED (GREEN)	Meaning
Steady	Power Supply is present.
ERR LED (YELLOW)	Meaning
Steady	Fault: insufficient power supply, faulty channel, faulty TC, internal communication error (signalled if the channel has been activated).
RX LED (RED)	Meaning
Steady	Data are being received through the RS485 communication port.

SENECA MI001230-E ENGLISH -4/16

TX LED (RED)	Meaning
Steady	Data are being transmitted through the RS485 communication
	port

Serial interface

SPEED SW112

For detailed information on RS485 serial interface, consult the documentation provided by the website www.seneca.it. in the section Prodotti/Serie Z-PC/MODBUS TUTORIAL

DIP-SWITCH SETTING

The instrument leaves the factory with all DIP-switches configured in position 0. The settings of the DIP-switches defines the module's communication parameters: address

In all the following tables, the indication • corresponds to a DIP-switch set in 1 (ON): no indication is provided when the DIP-switch is set in 0 (OFF).

3441	1.	4							
	9600 Baud								
		•	1	19200 Baud					
	•	П	3	84	00	Ва	aud		
	•	•	5	76	00	Ва	aud		
ADD									
SW1	3	4	5	6	7	8			
		Г					Communication Parameters from EEPROM (4)		
l	Г	Т	Т	П	Г		Fixed Address: 01		

	-	SS	_	_	_	_	
SW1	3	4	5	6	7	8	
							Communication Parameters from EEPROM (4)
	П		П		Г	•	Fixed Address: 01
	П	П	Г		•	П	Fixed Address: 02
	П	П	Г	П	•	•	Fixed Address: 03
	П	П	Г	•	Г	П	Fixed Address: 04
	X	Х	X	Х	X	Х	Fixed Address, as from binary representation.
	•	•	•	•		•	Fixed Address: 63

SW1	9	Not used.
	П	Leave to OFF position.
RS48	35	TERMINATOR
SW1	10	
	П	Terminator OFF.
	•	Terminator ON.

⁽⁴⁾ The default configuration is the following: Address 1, 38400, no parity, 1 stop bit.



MI001230-E

ENGLISH -5/16

ENGLISH -6/16

DEFAULT SETTING OF INPUT CHANNELS

The default configuration, valid for each pair of channels, belogging to the same group of terminals is the following

Both channels are enabled.

Type of returned Data : Cold junction Compensation : Active 50 Hz Rejection

ADC / Filter ADC: 15 bit, Filter: average. Thermocouple Type J for both channels.

FILTER SETTING

The filtering methods can be set for each pair of channels.

The filter consists of two independent low-pass filters

-FIR Filter , in running average, able to increase the rejection of disturbances to the mains power line frequency and to reduce measuring noise.

-IIR exponential Filter, with programmable time constant, able to dampen fluctuations.

If an input variation higher than the threshold T is detected, both filters are forced to adapt rapidly to the new value, stabilising it only later on. The value of the threshold in voltage is fixed and equal to 0,75 mV. The filter is set with the three least significant bits of registers MODBUS 40054..57 (refer to section MODBUS REGISTERS).

The following is a table containing all settable filter types. The propagation time (90%) is indicated for each filter, i.e. the maximum time between the step variation of the input and the variation of the number which represents it in the Modbus register, including the interrogation time of the single register (at 115 kbaud). The times indicated are valid if both the following conditions are respected

- Rejection set to 50 Hz. For 60 Hz rejection divide the times by 1,2.
- Only one of the two thermocouples of the same group is enabled. If both thermocouples are enabled, the propagation times approximately are doubled.

SET	SAME	PLING	FILTER	PROP. TIME 90%			
SEI	Bits ADC	Hz	TYPE	<t< th=""><th>>T</th></t<>	>T		
000	14	48	Not present	45 ms	45 ms		
001	14	20	Average	236 ms	103 ms		
010 (5)	15	11	Average	405 ms	179 ms		
011	15	11	Average + exp	1 s	179 ms		
100	15	11	Average + exp	3 s	179 ms		
101	15	11	Average + exp	8 s	179 ms		
110	15	11	Average + exp	24 s	179 ms		
111	15	11	Average + exp	72 s	179 ms		

MI001230-E

⁽⁵⁾ Default Value



Programming

For the product's programming and/or configuration tools, consult the website www.seneca.it.

During initial programming, the EEPROM (SW3 .. 8 in OFF position) default setting values originally programmed as follows can be used


Address = 1. SPEED = 38400 baud. PARITY = none. BIT NUMBER = 8. STOP BIT = 1.

The module can also be programmed through the front connector (COM) while paying attention to set the following connection parameters:

Address = 1. Speed = 2400 Baud. PARITY = none. STOP BIT = 1.

The COM communication port behaves in the same way as the RS485 bus port except for the communication parameters described above. It also has priority over the RS485 serial port and closes after 3 seconds of inactivity.

Frontal Panel and Led Position






MI001230-E

ENGLISH -7/16

Dimensions and Overall dimensions



This document is property of SENECA srl. Duplication and reprodution are forbidden, if not authorized. Contents of the present documentation refers to products and technologies described in it. All technical data contained in the document may be modified without prior notice Content of this documentation is subject to periodical revision.



SENECA s.r.l.

Via Germania, 34 - 35127 - Z.I. CAMIN - PADOVA - ITALY Tel. +39.049.8705355 - 8705359 - Fax +39.049.8706287 e-mail: info@seneca.it - www.seneca.it



MODBUS REGISTERS

Z-8TC has MODBUS 16 bits (words) registers, accessible by RS485 or RS232 serial communication. In the next paragraphs, we shall describe the supported MODBUS commands, and the functions of the registers.


Supported MODBUS Commands

Code	Function	Description
03 (*)	Read Holding Registers	Reading of word registers up to 32 at a time.
04 (*)	Read Input Registers	Reading of word registers up to 32 at a time.
06	Write Single Register	Writing of a word register.
16	Write Multiple Registers	Writing of word registers up to 32 at a time.

(*) The two functions have the same effect.

Holdina Reaisters

The 16-bit Holding Registers have the following structure:



In the table the notation Bit [x:y] indicates all bits from x to y. For example Bit [2:1] indicates bit 2 and bit 1, and serves to illustrate the meaning of the various united combinations of the values of the two bits. Remember that MODBUS functions 3, 4, 6 and 16, of single or multiple writing and reading, can be executed in the following registers. Default values are indicated with the * symbol.

REGISTER	Description	ADD.	R/W
MACHINE ID	Bit [15:8]: contain the module's ID: 24. Bit [7:0]: contain the firmware's revision.	40001	R
STATUS_INP	Status of input channels.	40002	R
Bit 15	1: Fault on channels 1 and 2.		
Bit 14	1: Fault on channels 3 and 4.		
Bit 13	1: Fault on channels 5 and 6.		
Bit 12	1: Fault on channels 7 and 8.		
Bit 11	1: Fault on the TC connected to channel 1.		



SENECA

MI001230-E

ENGLISH -9/16

Bit 10	1: Fault on the TC connected to channel 2.
Bit 9	1: Fault on the TC connected to channel 3.
Bit 8	1: Fault on the TC connected to channel 4.
Bit 7	1: Fault on the TC connected to channel 5.
Bit 6	1: Fault on the TC connected to channel 6.
Bit 5	1: Fault on the TC connected to channel 7.
Bit 4	1: Fault on the TC connected to channel 8.
Bit 3	1: Communication Error with channels 1 and 2.
Bit 2	1: Communication Error with channels 3 and 4.
Bit 1	1: Communication Error with channels 5 and 6.
Bit 0	1: Communication Error with channels 7 and 8.
CHAN1 TEN	Channel 1 measurement (tenths of °C or 40003 R
	tenths of µV).
Bit [15:0]	Temperature of channel 1 in tenths of °C (or
	voltage in tenths of μV).
CHAN2_TEN	Channel 2 measurement (tenths of °C or 40004 R
	tenths of μV).
Bit [15:0]	Temperature of channel 2 in tenths of °C (or
	voltage in tenths of μV).
CHAN3_TEN	Channel 3 measurement (tenths of °C or 40005 R
	tenths of µV).
Bit [15:0]	Temperature of channel 3 in tenths of °C (or
CHAN4 TEN	voltage in tenths of μV). Channel 4 measurement (tenths of °C or 40006 R
CHAN4_IEN	tenths of μV).
D:4 [4 E-0]	Temperature of channel 4 in tenths of °C (or
Bit [15:0]	voltage in tenths of μV).
CHAN5 TEN	Channel 5 measurement (tenths of °C or 40007 R
	tenths of µV).
Bit [15:0]	Temperature of channel 5 in tenths of °C (or
	voltage in tenths of μV).
CHAN6_TEN	Channel 6 measurement (tenths of °C or 40008 R
	tenths of µV).
Bit [15:0]	Temperature of channel 6 in tenths of °C (or
	voltage in tenths of μV).
CHAN7_TEN	Channel 7 measurement (tenths of °C or 40009 R
	tenths of μV).
Bit [15:0]	Temperature of channel 7 in tenths of °C (or voltage in tenths of uV).
	voitage in tentris or μν).

CHAN8_TEN	Channel 8 measurement (tenths of °C or tenths of µV).	40010	R
Bit [15:0]	Temperature of channel 8 in tenths of °C (or voltage in tenths of μV).		
CHAN1_FLOAT_H	Measurement of channel 1 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40011	R
Bit [15:0]	Temperature of channel 1 in °C or voltage in mV (MSW of the float).		
CHAN1_FLOAT_L	Measurement of channel 1 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40012	R
Bit [15:0]	Temperature of channel 1 in °C or voltage in mV (LSW of the float).		
CHAN2_FLOAT_H	Measurement of channel 2 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40013	R
Bit [15:0]	Temperature of channel 2 in °C or voltage in mV (MSW of the float).		
CHAN2_FLOAT_L	Measurement of channel 2 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40014	R
Bit [15:0]	Temperature of channel 2 in °C or voltage in mV (LSW of the float).		
CHAN3_FLOAT_H	Measurement of channel 3 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40015	R
Bit [15:0]	Temperature of channel 3 in °C or voltage in mV (MSW of the float).		
CHAN3_FLOAT_L	Measurement of channel 3 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40016	R
Bit [15:0]	Temperature of channel 3 in °C or voltage in mV (LSW of the float).		
CHAN4_FLOAT_H	Measurement of channel 4 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40017	R
Bit [15:0]	Temperature of channel 4 in °C or voltage in mV (MSW of the float).		
CHAN4_FLOAT_L	Measurement of channel 4 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40018	R
Bit [15:0]	Temperature of channel 4 in °C or voltage in mV (LSW of the float).		
CHAN5_FLOAT_H	Measurement of channel 5 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40019	R
Bit [15:0]	Temperature of channel 5 in °C or voltage in mV (MSW of the float).		

SSENECA

MI001230-E

ENGLISH -11/16

SOLINLOA	MIOU1230-E ENGL	юп - П	1/10
CHAN5_FLOAT_L	Measurement of channel 5 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40020	R
Bit [15:0]	Temperature of channel 5 in °C or voltage in mV (LSW of the float).		
CHAN6_FLOAT_H	Measurement of channel 6 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40021	R
Bit [15:0]	Temperature of channel 6 in °C or voltage in mV (MSW of the float).		
CHAN6_FLOAT_L	Measurement of channel 6 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40022	R
Bit [15:0]	Temperature of channel 6 in °C or voltage in mV (LSW of the float).		
CHAN7_FLOAT_H	Measurement of channel 7 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40023	R
Bit [15:0]	Temperature of channel 7 in °C or voltage in mV (MSW of the float).		
CHAN7_FLOAT_L	Measurement of channel 7 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40024	R
Bit [15:0]	Temperature of channel 7 in °C or voltage in mV (LSW of the float).		
CHAN8_FLOAT_H	Measurement of channel 8 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40025	R
Bit [15:0]	Temperature of channel 8 in °C or voltage in mV (MSW of the float).		
CHAN8_FLOAT_L	Measurement of channel 8 in floating point (see bit 15 of "AUX_SETTINGS" register: 40058).	40026	R
Bit [15:0]	Temperature of channel 8 in °C or voltage in mV (LSW of the float).		
STATUS_INP	Copy of register 40002 containing the status of the input channels.	40027	R
UNCT_TEN_IN1_2	Cold Junction Temperature of channels 1 and 2.	40028	R
Bit [15:0]	Cold junction temperature of channels 1 and 2, in tenths of °C.		
UNCT_TEN_IN3_4	Cold Junction Temperature of channels 3 and 4.	40029	R
Bit [15:0]	Cold junction temperature of channels 3 and 4, in tenths of °C.		
UNCT_TEN_IN5_6	Cold Junction Temperature of channels 5 and 6.	40030	R
Bit [15:0]	Cold junction temperature of channels 5 and 6, in tenths of °C.		

JUNCT_TEN_IN7_8	Cold Junction Temperature of channels 7 and 8.	40031	R
Bit [15:0]	Cold junction temperature of channels 7 and 8, in tenths of °C.		
ERR_CH1-2_CH3-4	Errors: Channels 1, 2 (MSB), Channels 3, 4 (LSB).	40037	R
Bit 15	1: Power supply voltage error (channels 1 and 2).		
Bit 14	1: Reception Error (channels 1 and 2).		
Bit 13	1: EEPROM saving Error (channels 1 and 2).		
Bit 12	1: EEPROM saving blocked (channels 1 and 2).		
Bit [11:9]	Reserved.]	
Bit 8	1: Reading Error CRC EEPROM (chan. 1 and 2).]	
Bit 7	1: Power supply voltage error (channels 3 and 4).		
Bit 6	1: Reception Error (channels 3 and 4).		
Bit 5	1: EEPROM saving Error (channels 3 and 4).	1	
Bit 4	1: EEPROM saving blocked (channels 3 and 4).		
Bit [3:1]	Reserved.		
Bit 0	1: Reading Error CRC EEPROM (chan. 3 and 4).		
ERR_CH5-6_CH7-8	Errors: Channels 5, 6 (MSB), Channels 7, 8 (LSB).	40038	R
Bit 15	1: Power supply voltage error (channels 5 and 6).		
Bit 14	1: Reception Error (channels 5 and 6).		
Bit 13	1: EEPROM saving Error (channels 5 and 6).		
Bit 12	1: EEPROM saving blocked (channels 5 and 6).		
Bit [11:9]	Reserved.		
Bit 8	1: Reading Error CRC EEPROM (chan. 5 and 6).		
Bit 7	1: Power supply voltage error (channels 7 and 8).		
Bit 6	1: Reception Error (channels 7and 8).		
Bit 5	1: EEPROM saving Error (channels 7 and 8).		
Bit 4	1: EEPROM saving blocked (channels 7 and 8).		
Bit [3:1]	Reserved.		
Bit 0	1: Reading Error CRC EEPROM (chan. 7 and 8).		
RESET	Module Reset.	40041	R/W
Bit [15:0]	Write value 0xCCCC to reset the module.		

SSENECA

MI001230-E

ENGLISH -13/16

SENECA

VAL FAULT 1 (6

MI001230-E

Value loaded in case of fault on channel 1 (expressed as 40003).⁽⁹⁾Default: 2000,0.

Filter of channels 1 and 2 (for details, refer to the

Thermocouple Type of Channel 1 (see THERMOCOUPLE TYPE Table). Default: Type J.

Thermocouple Type of Channel 2 (see THERMOCOUPLE TYPE Table). Default: Type J.

Register for the configuration of channels 3 and 4 See Register 40054, refering to channels 3 and 4

Register for the configuration of channels 5 and 6

See Register 40054, refering to channels 5 and 6

Register for the configuration of channels 7 and 8 See Register 40054, refering to channels 7 and 8

0 *: The high word of floating point is transmitte

1 : The low word of floating point is transmitted

1 : The temperature/voltage value is frozen at the last acquired value before fault is signalled.

Action in case of fault on channel 2 (As Bit 7).

Action in case of fault on channel 3 (As Bit 7).

Action in case of fault on channel 4 (As Bit 7).

Action in case of fault on channel 5 (As Bit 7).

Action in case of fault on channel 6 (As Bit 7).

Action in case of fault on channel 7 (As Bit 7).

Action in case of fault on channel 8 (As Bit 7).

001: Average filter

FILTER SETTING section):

instead of channels 1 and 2.

instead of channels 1 and 2.

instead of channels 1 and 2.

Floating point interpretation

first, then the low word.

first, then the high word.

programmed fault value

Reserved and not modifiable

Action in case of fault on channel 1 0 *: The temperature/voltage value is forced to the

Other settings in FILTER SETTING.

Configuration of Channels 3 and 4.

Configuration of Channels 5 and 6.

Configuration of Channels 7 and 8.

Additional Configuration Register.

000: Not present

40055 R/W

40056 R/W

40057 R/W

40058 R/W

ADDR (6) (7)	Register for the setting of the module's address and parity control.	40052	R/W
Bit [15:8]	Set the module's address. Permissible values from 0x00 to 0xFF (decimal values in the interval of 0-255). Default address: 1.		
Bit [7:0]	Set the type of parity control : 00000000* : No parity (NONE) (Default) 00000001 : Even parity (EVEN) 00000010 : Odd parity (ODD)		
BAUDR (6) (7)	Register for the setting of the baudrate and of the response delay time.	40053	R/W
Bit [15:8]	Set the value of the serial communicati speed (baudrate):		
Bit [7:0]	Set the response delay time in characters that represents the number of pauses of 6 characters each to be entered between the end of the Rx message and the start of the Tx message. Default value: 0.		
CONF_CH1_CH2 (6)	Configuration of Channels 1 and 2.	40054	R/W
Bit 15	Channel 1 Activation : 0 : Channel 1 is not active. 1 *: Channel 1 is active.		
Bit 14	Channel 2 Activation : 0 : Channel 2 is not active. 1 *: Channel 2 is active.		
Bit 13	Type of returned Data Item (Channels 1 and 2): 0*: Measurement in °C. 1: Measurement in mV.		
Bit 12	Cold junction Compensation Channels 1 and 2: 0: not active 1*: active		



Bit [10:8]

Bit [7:4]

Bit [3:0]

Bit [15:0]

Bit [15:0]

Bit [15:0]

Bit [14:8]

Bit 7

Rit 6

Bit 5

Bit 4

Rit 3

Bit 2

Bit 1

Bit 0

CONF CH3 CH4 (6)

CONF_CH5_CH6 (6)

CONF CH7 CH8 (6)

AUX_SETTINGS (6)

ENGLISH -15/16

Value loaded in case of fault on channel 2 (expressed as 40004). Default: 2000,0. VAL_FAULT_2 Value loaded in case of fault on channel 3 40061 R/W (expressed as 40005).[8] Default: 2000,0. VAL FAULT 3 ⁽⁶ VAL FAULT 4 Value loaded in case of fault on channel 4 40062 R/W (expressed as 40006).(8) Default: 2000,0. Value loaded in case of fault on channel 5 40063 R/W VAL FAULT 5 (6) (expressed as 40007).(8) Default: 2000,0. Value loaded in case of fault on channel 6 (expressed as 40008). Default: 2000,0. VAL FAULT 6 Value loaded in case of fault on channel 7 (expressed as 40009). (VAL FAULT 7 " Value loaded in case of fault on channel 8 (expressed as 40010). (8) Default: 2000,0. VAL_FAULT_8 (6 TABLE: THERMOCOUPLE TYPE FOR THE SETTING OF REGISTERS 40054..40057 THERMOCOUPLE TYPE THERMOCOUPLE TYPE 0 1 0 1 TC B 1 x x x Not implemented Not implemented The value is memorized in EEPROM memory. (7) The effect is at the reset (hardware or software) of the module. (8) The value in registers 40059..40066 is copied respectively in registers 40003..40010, when the corresponding bit in register 40058 is 0. The same value is converted in floating-point, and copied on the corresponding floating register. Disposal of Electrical & Electronic Equipment (Applicable throughout the European Union and other European countries with separate collection programs) This symbol, found on your product or on its packaging, indicates that this product should not be treated as household waste when you wish to dispose of it. Instead, it should be handed over to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could

- IQNet -

SENECA s.r.l. Via Germania, 34 - 35127 - Z.I. CAMIN - PADOVA - ITALY Tel. +39.049.8705355 - 8705359 - Fax +39.049.8706287



e-mail: info@seneca.it - www.seneca.

SENECA

1: 60 Hz

SENECA

otherwise be caused by inappropriate disposal of this product. The recycling of materials will help to conserve natural resources. For more detailed information about the recycling of this product, please contact your loca city office, waste disposal service or the retail store where you purchased this product.